

# Separator & Gasket Kit, Multi-Flavor Nozzle

## Instruction Sheet

Part Number 82-3457

### Installation Procedure

1. Insert Seal (PN 05-2159), flat side down, to bottom of Separator (PN 05-2158). See figure on reverse for reference.
2. Ensure that the Seal seats smooth and flat at the bottom of the Separator.
3. Check the performance of the seal by installing the Separator onto a nozzle and executing a water only pour.
4. If water exits the Syrup outlet, located directly below the nozzle, Seal has moved and must be readjusted.



6655 Lancer Blvd., San Antonio, Texas 78219 - 800-729-1500  
Technical Support/Warranty: 800-729-1550 [custserv@lancercorp.com](mailto:custserv@lancercorp.com)  
[lancercorp.com](http://lancercorp.com) - Lancer PN: 28-0560/02 - May 2017

"Lancer" is the registered trademark of Lancer © 2017 by Lancer, all rights reserved.

# Separator & Gasket Kit, Multi-Flavor Nozzle

## Instruction Sheet

Part Number 82-3457

### Installation Procedure

1. Insert Seal (PN 05-2159), flat side down, to bottom of Separator (PN 05-2158). See figure on reverse for reference.
2. Ensure that the Seal seats smooth and flat at the bottom of the Separator.
3. Check the performance of the seal by installing the Separator onto a nozzle and executing a water only pour.
4. If water exits the Syrup outlet, located directly below the nozzle, Seal has moved and must be readjusted.



6655 Lancer Blvd., San Antonio, Texas 78219 - 800-729-1500  
Technical Support/Warranty: 800-729-1550 [custserv@lancercorp.com](mailto:custserv@lancercorp.com)  
[lancercorp.com](http://lancercorp.com) - Lancer PN: 28-0560/02 - May 2017

"Lancer" is the registered trademark of Lancer © 2017 by Lancer, all rights reserved.

# Separator & Gasket Kit, Multi-Flavor Nozzle

## Instruction Sheet

Part Number 82-3457

### Installation Procedure

1. Insert Seal (PN 05-2159), flat side down, to bottom of Separator (PN 05-2158). See figure on reverse for reference.
2. Ensure that the Seal seats smooth and flat at the bottom of the Separator.
3. Check the performance of the seal by installing the Separator onto a nozzle and executing a water only pour.
4. If water exits the Syrup outlet, located directly below the nozzle, Seal has moved and must be readjusted.



6655 Lancer Blvd., San Antonio, Texas 78219 - 800-729-1500  
Technical Support/Warranty: 800-729-1550 [custserv@lancercorp.com](mailto:custserv@lancercorp.com)  
[lancercorp.com](http://lancercorp.com) - Lancer PN: 28-0560/02 - May 2017

"Lancer" is the registered trademark of Lancer © 2017 by Lancer, all rights reserved.

# Separator & Gasket Kit, Multi-Flavor Nozzle

## Instruction Sheet

Part Number 82-3457

### Installation Procedure

1. Insert Seal (PN 05-2159), flat side down, to bottom of Separator (PN 05-2158). See figure on reverse for reference.
2. Ensure that the Seal seats smooth and flat at the bottom of the Separator.
3. Check the performance of the seal by installing the Separator onto a nozzle and executing a water only pour.
4. If water exits the Syrup outlet, located directly below the nozzle, Seal has moved and must be readjusted.




6655 Lancer Blvd., San Antonio, Texas 78219 - 800-729-1500  
Technical Support/Warranty: 800-729-1550 [custserv@lancercorp.com](mailto:custserv@lancercorp.com)  
[lancercorp.com](http://lancercorp.com) - Lancer PN: 28-0560/02 - May 2017

"Lancer" is the registered trademark of Lancer © 2017 by Lancer, all rights reserved.

### Contents of Kit, 82-3457

<u>Item</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty</u>
01	05-2158	Separator, Nozzle, iFountain	1
02	05-2159	Seal, Separator, Nozzle, iFountain	1




**NOTE**

Please refer to the Lancer web site, ([www.lancercorp.com](http://www.lancercorp.com)) for information relating to Lancer Installation and Service Manuals, Instruction Sheets, Technical Bulletins, Service Bulletins, etc.

**LANCER**

### Contents of Kit, 82-3457

<u>Item</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty</u>
01	05-2158	Separator, Nozzle, iFountain	1
02	05-2159	Seal, Separator, Nozzle, iFountain	1




**NOTE**

Please refer to the Lancer web site, ([www.lancercorp.com](http://www.lancercorp.com)) for information relating to Lancer Installation and Service Manuals, Instruction Sheets, Technical Bulletins, Service Bulletins, etc.

**LANCER**

### Contents of Kit, 82-3457

<u>Item</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty</u>
01	05-2158	Separator, Nozzle, iFountain	1
02	05-2159	Seal, Separator, Nozzle, iFountain	1




**NOTE**

Please refer to the Lancer web site, ([www.lancercorp.com](http://www.lancercorp.com)) for information relating to Lancer Installation and Service Manuals, Instruction Sheets, Technical Bulletins, Service Bulletins, etc.

**LANCER**

### Contents of Kit, 82-3457

<u>Item</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty</u>
01	05-2158	Separator, Nozzle, iFountain	1
02	05-2159	Seal, Separator, Nozzle, iFountain	1



**NOTE**

Please refer to the Lancer web site, ([www.lancercorp.com](http://www.lancercorp.com)) for information relating to Lancer Installation and Service Manuals, Instruction Sheets, Technical Bulletins, Service Bulletins, etc.

**LANCER**