

# TwinPour Extended Splash Guard Install Kit

**Instruction Sheet** 

The following illustrates the steps necessary to install the new extended splash guards on an existing TwinPour dispenser.

## Conversion Kit - 82-6300

Part Number

I al Citallibei	<u>Description</u>
30-16316	Extended Splash Guard, Right, FS44
30-16317	Extended Splash Guard, Left, FS44
51-7039	Extended Splash Plate Assembly, FS44

Description

#### Installation Instructions

- Unplug the unit and remove the merchandiser.
- Remove the ice chute levers from the left and right ice chute assemblies.



Twist/Rotate one of the ADA panels, located on the unit's splash plate, to disengage from the unit.

### NOTE —

The left ADA panel must turn counterclockwise and the right ADA panel must turn clockwise to disengage from the unit.



Carefully pull ADA panel and electric wire harness from the unit's splash plate, until the harness connector is visible.

# NOTE —

It may be necessary to unhook the splash plate in order to pull the ADA panel harness through opening.



Disconnect the ADA Panel harness and remove from the unit. Repeat Steps 1 - 4 for second ADA panel.





# TwinPour Extended Splash Guard Install Kit

**Instruction Sheet** 

The following illustrates the steps necessary to install the new extended splash guards on an existing TwinPour dispenser.

#### Conversion Kit - 82-6300

<u>Part Number</u>	<u>Description</u>
30-16316	Extended Splash Guard, Right, FS44
30-16317	Extended Splash Guard, Left, FS44
51-7039	Extended Splash Plate Assembly, FS4

#### Installation Instructions

- 1. Unplug the unit and remove the merchandiser.
- Remove the ice chute levers from the left and right ice chute assemblies.



Twist/Rotate one of the ADA panels, located on the unit's splash plate, to disengage from the unit.

Lancer PN: 28-3032

The left ADA panel must turn counterclockwise and the right ADA panel must turn clockwise to disengage from the unit.



Carefully pull ADA panel and electric wire harness from the unit's splash plate, until the harness connector is visible.

# NOTE —

It may be necessary to unhook the splash plate in order to pull the ADA panel harness through opening.



Disconnect the ADA Panel harness and remove from the unit. Repeat Steps 1 - 4 for second ADA panel.



6. Remove the splash plate and cup rest/drip tray, (if necessary).



 Install the new extended splash plate (51-7039), included with kit, to the front of the unit.

# NOTE —

Make sure to feed wire harness for ADA panels through openings in front of new extended splash plate before installing to unit.



- Reconnect existing ADA panels to wire harness and reconnect to unit by inserting the panels and turning clockwise for the left side panel and counterclockwise for the right side panel.
- Install the left and right side splash guards (30-16316 and 30-16317), included with kit by first lining up the holes on the splash guards to the connection tabs on the edges of the splash plate.
- Once lined up, the splash guards then slide over the connection tabs on the splash plate. Push the splash guards down to secure to the splash plate.



11. Re-install ice chute levers and merchandiser, then plug in the unit.



 Remove the splash plate and cup rest/drip tray, (if necessary).



 Install the new extended splash plate (51-7039), included with kit, to the front of the unit.

# NOTE —

Make sure to feed wire harness for ADA panels through openings in front of new extended splash plate before installing to unit.



- Reconnect existing ADA panels to wire harness and reconnect to unit by inserting the panels and turning clockwise for the left side panel and counterclockwise for the right side panel.
- 4. Install the left and right side splash guards (30-16316 and 30-16317), included with kit by first lining up the holes on the splash guards to the connection tabs on the edges of the splash plate.
- Once lined up, the splash guards then slide over the connection tabs on the splash plate. Push the splash guards down to secure to the splash plate.



 Re-install ice chute levers and merchandiser, then plug in the unit.



2