INSTALLATION INSTRUCTIONS FOR DROP-IN DISPENSER SLIDE IN CONVERSION STAND

(3023, PN 84-0059; 2323, PN 84-0058; 1522, PN 84-0006)

1. INSTALLATION PROCEDURES

<u>NOTE</u>

This Instruction Sheet applies to the following Dispensers: 3023, 2323, and 1523.

1.1 UNPACKING

- A. The assembled Slide-In Conversion Stand (See Figure 1 on reverse) is shipped in a corrugated shipping carton.
- B. Carefully remove the Unit from the corrugated shipping carton.

NOTE

Four (4) legs are included with the stand.

1.2 INSTALLATION OF DROP-IN DISPENSERS

- A. Install four (4) legs (Item 2, Figure 1) to Conversion Stand.
- B. Remove six (6) screws (Item 6, Figure 1) to remove one panel (Item 5, Figure 1) from rear of Conversion Stand. Save screws for reinstallation.

<u>NOTE</u>

It is NOT necessary to remove more than one panel to accomplish this installation.

- C. Slightly lift the drop-in dispenser and carefully slide the dispenser into the Conversion Stand. Carefully set the dispenser down into the Conversion Stand.
- D. Make electrical, water, syrup, and drain connections in accordance with the manufacturer's instructions.
- E. Reinstall panel and secure with six (6) screws removed in Step 1.2.B above.

Please refer to the Lancer web site (www.lancercorp.com) for information relating to Lancer Installation and Service Manuals, Instruction Sheets, Technical Bulletins, Service Bulletins, etc.




6655 LANCER BLVD. • SAN ANTONIO, TEXAS 78219 USA • (210) 310-7000

FAX SALES

NORTH AMERICA – 210-310-7245 • INTERNATIONAL SALES – 210-310-7242 • CUSTOMER SERVICE – 210-310-7242 • LATIN AMERICA – 210-524-9567 / 210-310-7245 • EUROPE – 32-2-755-2399 • PACIFIC – 61-8-8268-1978 •

FAX ENGINEERING: • 210-310-7096 DATE: 01/29/99 P.N.: 28-0285/02



LIST OF COMPONENTS, 3023 DISPENSER				LIST OF COMPONENTS, 2323 DISPENSER				LIST OF COMPONENTS, 1522 DISPENSER			
<u>ITEM</u>	PART NO.	DESCRIPTION	QTY	<u>ITEM</u>	PART NO.	DESCRIPTION	<u>QTY</u>	ITEM	PART NO.	DESCRIPTION	<u>QTY</u>
1	51-1274	Bottom Assy, Conversion Stand	1	1	51-0970	Bottom Assy, Conversion Stand	1	1	51-1269	Bottom Assy, Conversion Stand	1
2	81-0011	Leg, Adjustable, 6.0 Inches Tall	4	2	81-0011	Leg, Adjustable, 6.0 Inches Tall	4	2	81-0011	Leg, Adjustable, 6.0 Inches Tall	4
3	51-1266	Side Panel, Left/Right Conversion Stand	2	3	51-1266	Side Panel, Left/Right Conversion Stand	2	3	51-1266	Side Panel, Left/Right Conversion Stand	2
4	30-2522	Panel, Bottom, Front/Back Conversion Stand	2	4	30-1771/01	Panel, Bottom, Front/Back Conversion Stand	2	4	30-2507	Panel, Bottom, Front/Back Conversion Stand	2
5	30-2521	Panel, Top, Front/Back Conversion Stand	2	5	30-1770/01	Panel, Top, Front/Back Conversion Stand	2	5	30-2506	Panel, Top, Front/Back Conversion Stand	2
6	04-0148	Screw, 10 - 32 x 0.250	24	6	04-0148	Screw, 10 - 32 x 0.250	24	6	04-0148	Screw, 10 - 32 x 0.250	24
7	04-0033	Washer, 1/4	10	7	04-0033	Washer, 1/4	10	7	04-0033	Washer, 1/4	10
8	04-0520	Screw, 1/4 - 20 x 0.500	10	8	04-0520	Screw, 1/4 - 20 x 0.500	10	8	04-0520	Screw, 1/4 - 20 x 0.500	10