



# LEV Fill Station Store Operations Guide

<b>OPERATING MODE</b>	<b>AUDIBLE ALARM</b>	<b>LIGHT ON</b>	<b>SWITCH POSITION</b>
<b>Normal On</b>	<b>Off</b>	<b>Green</b>	<b>“AUTO”</b>
<b>Manual Fill</b>	<b>Off</b>	<b>Green</b>	<b>“MANUAL”</b>
<b>Off</b>	<b>Off</b>	<b>None</b>	<b>“OFF”</b>
<b>Syrup or CO2 Out</b>	<b>On</b>	<b>Flashing</b>	<b>“AUTO”</b>

**NOTE:** To disable alarm sound, move switch from “AUTO” to “MANUAL”, then back to “AUTO”. Light will continue to flash.